


Understanding PEC Probe Selection & Footprint (Lyft 1.1)

This reference document is designed to assist you in selecting the PEC probe that is best suited to your application with Lyft software version 1.1. Knowing the nominal thickness of the component to be inspected and the nominal insulation/coating thickness in place, the selection table below suggests the adequate probe.

The remaining information helps understand and determine the footprint of the selected probe, the averaging area, and the edge effect. This is especially useful in quantifying the performance of the Lyft solution in a variety of conditions.


Selecting the Right PEC Probe

Reference the chart to choose a probe.



Footprint

The footprint (FP) of a probe is used to determine the **best grid resolution** for proper CUI detection. FP is defined as the **full** width at half maximum (FWHM) of the response detected by the probe. So doing, ensuring a 50% signal overlap between each point on the grid map.



Calculating the PEC Probe Footprint

Use the following formula to determine your probe's footprint.

 $FP \approx 0.65 \times LO + FP_{o}$

Where:

LO is the **liftoff** (insulation, jacket, coating thickness).

PEC-025

 $FP_0 = 35 \text{ mm} (1.38 \text{ in})$


			Insulation / Coating Thickness (Liftoff)														
		mm	0	6	13	19	25	38	51	64	76	89	102	127	152	178	203
		in	0.00	0.25	0.50	0.75	1.00	1.50	2.00	2.50	3.00	3.50	4.00	5.00	6.00	7.00	8.00
FOOTPRINT	PEC-025	mm	35	39	43	47	52	-	-	-	-	-	-	-	-	_	-
		in	1.38	1.54	1.70	1.87	2.03	-	-	-	-	-	-	-	-	-	-
	PEC-089 PEC-SZ-089	mm	62	66	70	74	79	87	95	103	112	120	128	1 45	161		
		in	2.44	2.61	2.77	2.93	3.09	3.42	3.74	4.07	4.39	4.72	5.04	5.69	6.34		
	PEC-152	mm	100	104	108	112	117	125	133	141	150	158	166	183	199	216	232
		in	3.94	4.10	4.26	4.43	4.59	4.91	5.24	5.56	5.89	6.21	6.54	7.19	7.84	8.49	9.14

Averaging Area

This is the entire surface viewed by the probe on the component. The wall thickness determined by Lyft is the average wall thickness within the averaging area. As a result, corrosion flaws smaller than the averaging area are underestimated. The averaging area is **1.8 times** the probe footprint (AvgA = **1.8 × FP**).

Edge Effect

The edge effect impacts PEC measurements when a probe **nears geometry variations** such as nozzles, flanges, or the end of a structure. Measurements begin to vary from a distance of one FP from the center of a probe's coils.



FP_o is the footprint at a **liftoff of zero**. For each probe, FP_o is:

PEC-089/PEC-SZ-089

 $FP_0 = 62 \text{ mm} (2.44 \text{ in})$

PEC-152

 $FP_0 = 100 \text{ mm} (3.94 \text{ in})$

www.eddyfi.com